

LabelEase Version 4.2 Readme

© 2007-2015 by Honeywell International, Inc.
All Rights Reserved

In this Release

This Readme document contains release notes for LabelEase 4.2. It includes installation information as well as instructions for getting started with the program and new features available in version 4.2.

Support

For	Contact
Updates and release notes	esd.notifier.com
LabelEase support report errors, suggest changes, or get updates	HFS.Interactive.Media@honeywell.com

Installation

Your System

To install and run this program, your system will need the following:

- Microsoft Windows XP, Windows Vista, or Windows 7/8.
- Administrative privileges on the system.
- Microsoft Internet Explorer 8 or higher.
- Super VGA monitor with a screen resolution set to at least 1024 x 758, small fonts.
- 1GB of RAM.

Installation Notes

Reboot — If Windows prompts you to reboot your system, do so or LabelEase may not run properly.

Uninstalling the program — Select LabelEase from the Windows Control Panel Add/Remove Programs feature.

Getting Started with LabelEase

Starting a new Label:

- Open LabelEase
- On the LabelEase Projects screen select the label you wish to start by selecting the appropriate label icon on the Annunciator or Panel Module tab.
- Double-click on the selected label icon or select "Open" to start the new label.

Editing Text Boxes:

Most labels have editable text areas in which custom text can be added to labels. There are two ways to edit these text areas:

- 1) Double-Click on a text area to bring up the "Edit Text" dialog box.
- 2) Select a text area then from the program menu select Format -> Text -> Content. This will also bring up the "Edit Text" dialog box.

Add custom text to the "Edit Text" dialog box. Text formatting such as font, color, and text size can all be adjusted inside the "Edit Text" dialog box.

Adding Graphics:

There are several ways to add graphics to labels. To add graphics to a label:

- 1) Drag and drop graphics from the included graphic library onto labels. These graphics are located in the left hand column of the program
- 2) Custom graphics can be added to labels by selecting Insert -> Picture from the program menu.

Adding new Shapes:

New shapes can be added to labels to better customize them. From the program toolbar you are able to select from rectangles, ellipses, lines, arcs and freeform design. Text can be added to all rectangle and ellipse shapes as well as shading and color.

Version History

New Release: Version 4.2 – April 2015

- Added the following labels to the program:
 - NFC-50/100 (Top Row and Bottom Row labels)
 - NFC-FFT Fire Fighters Telephone
 - NFC-RPU Remote Paging Unit
- Added the following Notifier Australia labels to the program:
 - ACM-ZM8 LED Mimic Annunciator - 8 Zones
 - AEM-ZM8 LED Mimic Expander - 8 Zones
 - CFP-16 Conventional Control Panel - Name Plate
 - SCS-8AU Smoke Control Station – Dampers
 - SCS-8AU Smoke Control Station – Fans
 - LCD2-80 LCD Annunciator
- Minor bug fixes and interface changes.

New Release: Version 4.1 – 1/22/2009

- Added the LCD2-80 Label.
- Corrected the graphic for System Board 1 inside the program.
- Updated the Live Update feature.

Internet Update: Version 4.0.1 – 11/19/2008

- Updated the graphics library to make all graphics transparent on labels.

- Update program enhanced.

Initial Release: Version 4.0 – 4/11/2008